Standard canal **OPTION ISO 025**

R-Motion®







Reciprocating motion (counterclockwise)





- Create straight-line coronal and radicular access
- Use an ISO 010 hand file to explore the canal
- Determine the working length (WL)



- Progress with R-Motion Glider down to WL with gentle 2-3 mm strokes (max. 3)
- Irrigate and recapitulate



- •Use the appropriate R-Motion shaping file with gentle 2-3 mm strokes (max. 3), applying very light apical pressure and allowing file to passively progress along the canal until reaching the WL
- Irrigate and recapitulate



- Once the canal has been shaped, proceed with the cleaning of the canal
- Obturate by selecting the appropriate GP point and sealer









R-Motion®



INFO

Preoperative radiographs Access preparation Determine the working length (WL)

GLIDE PATH



Use of the R-Motion Glider C is recommended for canals which require an instrument with more rigidity, and/or if the R-Motion Glider is no longer progressing and can not reach the working length.

SHAPING FILE SELECTION*



* Select the R-Motion single-file shaping instrument which is best suited to the anatomy of the canal being treated. If the radiographs do not allow you to clearly identify the anatomy of the canal, it can be gauged using hand files.













